



SR200-V4-A20

Intel® 9th Gen Coffee Lake Xeon® Military
Rugged MXM GPU Computer



User's Manual

Revision Date: Dec.09.2024

Safety Information

Electrical safety

- To prevent electrical shock hazard, disconnect the power cable from the electrical outlet before relocating the system.
- When adding or removing devices to or from the system, ensure that the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- Before connecting or removing signal cables from the motherboard, ensure that all power cables are unplugged.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Make sure that your power supply is set to the correct voltage in your area.
- If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your local distributor.

Operation safety

- Before installing the motherboard and adding devices on it, carefully read all the manuals that came with the package.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- To avoid short circuits, keep paper clips, screws, and staples away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity, and temperature extremes. Do not place the product in any area where it may become wet.
- Place the product on a stable surface.
- If you encounter any technical problems with the product, contact your local distributor

Statement

- All rights reserved. No part of this publication may be reproduced in any form or by any means, without prior written permission from the publisher.
- All trademarks are the properties of the respective owners.
- All product specifications are subject to change without prior notice

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Revision History

Revision	Date (yyyy/mm/dd)	Changes
Version 1.0	2024/12/09	Initial release at SR200-X4-A20
Version 2.0	2025/7/28	Change to 370 x 205 x 89.5mm 版 Change front I/O placement Change MB: OXY5741B-04 VA1 版 Change to ATX mode (remove jumper at JP5) Change MXM A2000 8GB 35W 版 Remove "7STARLAKE" Logo

Packing list

■	SR200-X4-A20 Rugged Fanless System
■	CD (Driver)
■	M12 Power Cable

Ordering information

Model Number	Description
SR200-X4-A204	IP65 MIL-STD-810G Rugged Computer with Intel® 9th Gen Coffee Lake Xeon® E-2276ML Processor 9V to 36V DC-in, Extended Temp -40 to 60°C + NVIDIA RTX MXM A2000 4G



If any of the above items is damaged or missing, please contact your local distributor.

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Table Contents

Safety Information	1
Packing list	2
Ordering information	2
Table Contents	3
Chapter 1: Product Introduction	5
1.1 Key Features	5
1.2 Appearance	6
1.3 Dimension	7
1.4 System Diagram block	8
Chapter 2: Connector pin definition	9
Chapter 3: AMI BIOS UTILITY	10
3.1 Starting	10
3.2 Navigation Keys	10
3.3 Main Menu	10
3.4 Advanced Menu	11
3.4.1 CPU Configuration	12
3.4.2 Power & Performance	13
3.4.3 PCH-FW Configuration	14
3.4.4 AMT Configuration	15
3.4.4.1 CIRA Configuration	16
3.4.4.2 ASF Configuration	17
3.4.4.3 Secure Erase Configuration	18
3.4.4.4 OEM Flags Settings	19
3.4.4.5 MEBx Resolution Settings	20
3.4.5 Trusted Computing	22
3.4.6 ACPI Setting	24
3.4.7 IT8786 Super IO Configuration	25
3.4.7.1 Serial Port 1 Configuration	25
3.4.7.2 Serial Port 2 Configuration	26
3.4.8 Hardware Monitor	27
3.4.8.1 Smart Fan Function	27
3.4.8.2 System Fan Setting	28
3.4.9 PCI Subsystem Settings	29
3.4.10 USB Configuration	30
3.4.11 CSM Configuration	31

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.12 NVMe Configuration	32
3.4.13 Network Stack Configuration	33
3.5 Chipset	34
3.5.1 System Agent (SA) Configuration	34
3.5.2 PCH-IO Configuration	36
3.5.2.1 PCI Express Configuration	37
3.5.2.2 SATA And RST Configuration.....	39
3.5.2.3 Security Configuration	40
3.6 Security.....	42
3.6.1 Administrator Password	42
3.6.2 User Password.....	43
3.6.3 Secure Boot	43
3.6.3.1 Restore Factory Keys	44
3.6.3.2 Key Management	44
3.6.3.3 Install factory defaults.....	45
3.6.3.4 File System	45
3.6.3.5 File System	46
3.6.3.6 Restore DB defaults.....	46
3.6.3.7 Platform Key(PK)	47
3.6.3.8 Key Exchange keys.....	47
3.6.3.9 Authorized Signatures.....	48
3.6.3.10 Forbidden Signatures	48
3.6.3.11 Authorized Time Stamps.....	49
3.6.3.12 OS Recovery Signatures	49
3.7 Boot.....	50
3.8 Save & Exit.....	51
3.8.1 Save Changes and Exit.....	51
3.8.1.1 Save & Exit Setup	51
3.8.2 Exit without Saving.....	52
3.8.3 Save & reset	52
3.8.4 Reset Without Saving.....	53
3.8.5 Save Setup Values	53
3.8.6 Load Previous Values.....	54
3.8.7 Load Optimized Defaults.....	54
3.8.8 Save Values as User Defaults.....	55
3.8.9 Restore User Defaults	55

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Chapter 1: Product Introduction

1.1 Key Features

System	
CPU	Intel® 9th Gen Coffee Lake Xeon® E-2276ML Processor
MB	OXY5741B-04 VA1
BIOS	AMI UEFI BIOS
Memory Type	4x DDR4 SO-DIMM 2666MHz (1x 32GB, Up to 128G)
Graphic	Intel® UHD Graphic 630
Chipset	Intel® CM246
TPM	YPM2.0(SLB9665)
GPU	MXM NVIDIA® RTX™ A2000 2,560 CUDA® cores , 8GB GDDR6 memory, 35W
Display	4x DP up to 4096 x 2304 60@Hz
Storage Device	1x M.2 2280 4TB SSD
	4x SATA III
Ethernet	Intel® I210iT & I219LM GbE LAN (10/100/1000 Mbps supported)
Audio Code	ALC888S
PCIe/104	1x Type 2
Front I/O	
Power Button	1x Power Button w/Indicator LED
LAN	2x RJ45 LAN
COM	1x DB-9 (RS232/422/485)
USB	4x USB 3.0
Display Port	4x DP, resolution up to 4096 x 2304
Power In	1x 9V~36V DC-IN with M12 Connector
Rear I/O	
Ground Screw	1x (M4)
Audio	1x Mic-in
	1x Line-out
Mechanical & Environment	
Constructio	Aluminum chassis with fanless design
Power requirement	9V ~ 36V DC-IN
Dimension	370 x 205 x 89.5mm (W x D x H)
Operating Temp.	-40 to 60°C
Storage Temp	-40 to 85°C

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Relative Humidity	5% t0 95%, non-condensing
*Specification are subject to change without notice.	
Cable Kit	
M12 Power cable	1x

1.2 Appearance

Front IO




Back IO



SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024


1.3 Dimension



SR200-X4-A20 User's Manual


Revision Date: Dec.09.2024

1.4 System Diagram block



Chapter 2: Connector pin definition

1. M12 POWER Connector: CON1 / Power Cable :CON2



COLOR	CON1	CON2	
BROWN	1	TN1	Vin+
WHITE	2	TN1	Vin+
BLUE	3	TN2	Vin-
BLACK	PE	TN2	Vin-

Chapter 3: AMI BIOS UTILITY

This chapter provides users with detailed descriptions on how to set up a basic system configuration through the AMI BIOS setup utility.

3.1 Starting

To enter the setup screens, perform the following steps:

- Turn on the computer and press the key immediately.
- After the key is pressed, the main BIOS setup menu displays. Other setup screens can be accessed from the main BIOS setup menu, such as the Chipset and Power menus.

3.2 Navigation Keys

The BIOS setup/utility uses a key-based navigation system called hot keys. Most of the BIOS setup utility hot keys can be used at any time during the setup navigation process.

Some of the hot keys are <F1>, <F10>, <Enter>, <ESC>, and <Arrow> keys.

Left/Right	The Left and Right <Arrow> keys moves the cursor to select a menu.
Up/Down	The Up and Down <Arrow> keys moves the cursor to select a setup screen or sub-screen.
+– Plus/Minus	The Plus and Minus <Arrow> keys changes the field value of a particular setup setting.
Tab	The <Tab> key selects the setup fields.
F1	The <F1> key displays the General Help screen.
F10	The <F10> key saves any changes made and exits the BIOS setup utility.
Esc	The <Esc> key discards any changes made and exits the BIOS setup utility.
Enter	The <Enter> key displays a sub-screen or changes a selected or highlighted option in each menu.


3.3 Main Menu

The Main menu is the screen that first displays when BIOS Setup is entered, unless an error has occurred.

When you first enter the BIOS Setup Utility, you will encounter the Main setup screen. You can always return to the Main setup screen by selecting the Main tab. There are two Main Setup options. They are described in this section. The Main BIOS Setup screen is shown below.

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024



The Main BIOS setup screen has two main frames. The left frame displays all the options that can be configured. Grayed-out options cannot be configured; options in blue can. The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.

● System Date

Use this function to change the system date.

Select System Date using the Up and Down <Arrow> keys. Enter the new values through the keyboard. Press the Left and Right <Arrow> keys to move between fields. The date setting must be entered in MM/DD/YY format.

● System Time

Use this function to change the system time.

Select System Time using the Up and Down <Arrow> keys. Enter the new values through the keyboard. Press the Left and Right <Arrow> keys to move between fields. The time setting is entered in HH:MM:SS format.

Note: The time is in 24-hour format. For example, 5:30 A.M. appears as 05:30:00, and 5:30 P.M. as 17:30:00.

● Access Level

Display the access level of the current user in the BIOS.

3.4 Advanced Menu


The Advanced Menu allows you to configure your system for basic operation. Some entries

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024


are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.

Setting incorrect field values may cause the system to malfunction.



3.4.1 CPU Configuration

This section is used to view CPU status and configure CPU parameters.




SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	Intel(VMX) Virtualization Technology
Default Value	[Enabled]
Possible Value	Disabled Enabled
Field Name	Active Processor Cores
Default Value	[A11]
Possible Value	A11 1 2 3 4 5

Field Name	Hyper-Threading
Default Value	[Enabled]
Possible Value	Disabled Enabled

3.4.2 Power & Performance




Field Name	Intel® SpeedStep™
Default Value	[Enabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	Turbo Mode
Default Value	[Enabled]
Possible Value	Disabled Enabled
Field Name	C States
Default Value	[Disabled]
Possible Value	Disabled Enabled

3.4.3 PCH-FW Configuration



Field Name	ME State
Default Value	[Enabled]
Possible Value	Disabled Enabled


Field Name	Manageability Feature State
Default Value	[Enabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	AMT BIOS Features
Default Value	[Enabled]
Possible Value	Disabled Enabled

3.4.4 AMT Configuration




Field Name	ASF support
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	USB Provisioning of AMT
Default Value	[Disabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.4.1 CIRA Configuration




Field Name	ASF support
Default Value	[Enabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.4.2 ASF Configuration



Field Name	PET Progress
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	WatchDog
Default Value	[Disabled]
Possible Value	Disabled Enabled

Field Name	ASF Sensors Table
Default Value	[Disabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.4.3 Secure Erase Configuration




Field Name	Secure Erase mode
Default Value	[Simulated]
Possible Value	Simulated Real

Field Name	Force Secure Erase
Default Value	[Disabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.4.4 OEM Flags Settings



Field Name	MEBx hotkey Pressed
Default Value	[Disabled]
Possible Value	Disabled Enabled

Field Name	MEBx Selection Screen
Default Value	[Disabled]
Possible Value	Disabled Enabled

Field Name	Hide Unconfigure ME Confirmation Prompt
Default Value	[Disabled]
Possible Value	Disabled Enabled


Field Name	MEBx OEM Debug Menu Enable
Default Value	[Disabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	Unconfigure ME
Default Value	[Disabled]
Possible Value	Disabled Enabled

3.4.4.5 MEBx Resolution Settings



Field Name	Non-UI Mode Resolution
Default Value	[Auto]
Possible Value	Auto 80x25 100x31


Field Name	UI Mode Resolution
Default Value	[Auto]
Possible Value	Auto 80x25 100x31

Field Name	Graphics Mode Resolution
Default Value	[Auto]
Possible Value	Auto

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

	640x480
	800x600
	1024x768




Field Name	Pending operation
Default Value	[None]
Possible Value	None TPM Clear

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.5 Trusted Computing



Field Name	Security Device Support
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	SHA-1 PCR Bank
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	SHA256 PCR Bank
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	Pending operation
Default Value	[None]
Possible Value	None TPM Clear

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	Platform Hierarchy
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	Storage Hierarchy
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	Endorsement Hierarchy
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	TPM2.0 UEFI Spec Version
Default Value	[TCG_2]
Possible Value	TCG_1_2 TCG_2


Field Name	Physical Presence Spec Version
Default Value	[1.3]
Possible Value	1.2 1.3

Field Name	Device Select
Default Value	[Auto]
Possible Value	TPM 1.2 TPM 2.0 Auto

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.6 ACPI Setting



Field Name	Enable ACPI Auto Configuration
Default Value	[Disabled]
Possible Value	Disabled Enabled

Field Name	Enable Hibernation
Default Value	[Enabled]
Possible Value	Disabled Enabled


Field Name	ACPI Sleep State
Default Value	[S3(Suspend to RAM)]
Possible Value	Suspend Disabled S3(Suspend to RAM)

Field Name	Lock Legacy Resources
Default Value	[Disabled]
Possible Value	Disabled Enabled


SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.7 IT8786 Super IO Configuration



3.4.7.1 Serial Port 1 Configuration



Field Name	Serial Port
Default Value	[Enabled]

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Possible Value	Disabled Enabled
Field Name	COM1 Control
Default Value	[RS232]
Possible Value	Loopback RS-232 RS-485 Half Duplex RS-485/422 Full Duplex

3.4.7.2 Serial Port 2 Configuration




Field Name	Serial Port
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	COM1 Control
Default Value	[RS232]
Possible Value	Loopback RS-232 RS-485 Half Duplex RS-485/422 Full Duplex


SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.8 Hardware Monitor



3.4.8.1 Smart Fan Function




SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	FAN_CTL Polarity
Default Value	[Active high]
Possible Value	Active low Active high
Field Name	Smoothing control
Default Value	[4Hz]
Possible Value	1Hz 16Hz 8Hz 4Hz

3.4.8.2 System Fan Setting



Field Name	Smart Fan Mode
Default Value	[Automatic Mode]
Possible Value	Software Mode Automatic Mode


Field Name	System Fan Type
Default Value	[PWM]
Possible Value	PWM RPM

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	Temperature Select
Default Value	[TMP IN3]
Possible Value	TMP IN1 TMP IN2 TMP IN3

3.4.9 PCI Subsystem Settings




Field Name	Above 4G Decoding
Default Value	[Disabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.10 USB Configuration



Field Name	Legacy USB Support
Default Value	[Enabled]
Possible Value	Enabled Disabled Auto

Field Name	XHCI Hand-Off
Default Value	[Enabled]
Possible Value	Enabled Disabled

Field Name	USB Mass Storage Driver Support
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	USB transfer time-out
Default Value	[20 sec]
Possible Value	1 sec

SR200-X4-A20 User's Manual


Revision Date: Dec.09.2024

	5 sec 10 sec 20 sec
--	---------------------------

Field Name	Device reset time-out
Default Value	[20 sec]
Possible Value	1 sec 5 sec 10 sec 20 sec

Field Name	Device Power-up delay
Default Value	[Auto]
Possible Value	Auto Manual

3.4.11 CSM Configuration





Field Name	CSM Support
Default Value	[Disabled]

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Possible Value	Disabled
	Enabled


3.4.12 NVMe Configuration



SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.4.13 Network Stack Configuration





Field Name	Network Stack
Default Value	[Disabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.5 Chipset

3.5.1 System Agent (SA) Configuration



Field Name	Primary Display
Default Value	[Auto]
Possible Value	Auto IGFX

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

	PEG PCI SG
--	------------------

Field Name	Internal Graphics
Default Value	[Auto]
Possible Value	Auto Disabled Enabled

Field Name	GTT Size
Default Value	[8MB]
Possible Value	2MB 4MB 8MB

Field Name	Aperture Size
Default Value	[256MB]
Possible Value	128MB 256MB 512MB 1024MB 2048MB

Field Name	DVMT Pre-Allocated
Default Value	[32M]
Possible Value	0M 32M 64M 4M 8M 12M 16M 20M 24M 28M 32M/F7

SR200-X4-A20 User's Manual


Revision Date: Dec.09.2024

	36M
	40M
	44M
	48M
	52M
	56M
	60M


Field Name	DVMT Total Gfx Mem
Default Value	[128M]
Possible Value	128M 256M MAX

Field Name	Above 4GB MMIO BIOS assignment
Default Value	[Enabled]
Possible Value	Enabled Disabled


3.5.2 PCH-IO Configuration



3.5.2.1 PCI Express Configuration



Field Name	PCIe function swap
Default Value	[Disabled]
Possible Value	Disabled Enabled



SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024



Field Name	PCI Express Root Port 1
Default Value	[Enabled]

Field Name	PCI Express Root Port 5
Default Value	[Enabled]


Field Name	PCI Express Root Port 10
Default Value	[Enabled]

Field Name	PCI Express Root Port 11
Default Value	[Enabled]

Field Name	PCI Express Root Port 12
Default Value	[Enabled]

Field Name	PCI Express Root Port 13
Default Value	[Enabled]

3.5.2.2 SATA And RST Configuration



Field Name	SATA Controller(s)
Default Value	[Enabled]
Possible Value	Enabled Disabled

Field Name	SATA Mode Selection
Default Value	[AHCI]
Possible Value	AHCI Intel RST Premium With Intel Optane System Acceleration

Field Name	M.2 Port
Default Value	[Disabled]
Possible Value	Disabled Enabled

Field Name	Port 1
Default Value	[Enabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	Port 2
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	Port 3
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	Port 4
Default Value	[Enabled]
Possible Value	Disabled Enabled

3.5.2.3 Security Configuration



Field Name	RTC Memory Lock
Default Value	[Enabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

Field Name	BIOS Lock
Default Value	[Enabled]
Possible Value	Disabled Enabled

Field Name	Force unlock on all GPIO pads
Default Value	[Disabled]
Possible Value	Disabled Enabled

Field Name	PCH LAN Controller
Default Value	[Enabled]
Possible Value	Enabled Disabled

Field Name	Wake on LAN Enable
Default Value	[Enabled]
Possible Value	Enabled Disabled

Field Name	State After G3
Default Value	[S5 State]
Possible Value	S0 State S5 State



Field Name	SPD Write Disable
Default Value	[TRUE]
Possible Value	TRUE FALSE

SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.6 Security


3.6.1 Administrator Password




SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.6.2 User Password



3.6.3 Secure Boot




Field Name	Secure Boot
Default Value	[Enabled]
Possible Value	Disabled Enabled

SR200-X4-A20 User's Manual


Revision Date: Dec.09.2024

Field Name	Secure Boot Mode
Default Value	[Custom]
Possible Value	Standard Custom

3.6.3.1 Restore Factory Keys



3.6.3.2 Key Management




SR200-X4-A20 User's Manual


Revision Date: Dec.09.2024

Field Name	Factory Key Provision
Default Value	[Disabled]
Possible Value	Disabled Enabled

3.6.3.3 Install factory defaults




3.6.3.4 File System




SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024


3.6.3.5 File System




3.6.3.6 Restore DB defaults




3.6.3.7 Platform Key(PK)




3.6.3.8 Key Exchange keys




3.6.3.9 Authorized Signatures




3.6.3.10 Forbidden Signatures



3.6.3.11 Authorized Time Stamps




3.6.3.12 OS Recovery Signatures



SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024

3.7 Boot




Field Name	Bootup NumLock State
Default Value	[Off]
Possible Value	On Off

Field Name	Quiet Boot
Default Value	[Enabled]
Possible Value	Disabled Enabled


Field Name	Fast Boot
Default Value	[Disable Link]
Possible Value	Disable Link Enabled

3.8 Save & Exit


3.8.1 Save Changes and Exit




3.8.1.1 Save & Exit Setup




3.8.2 Exit without Saving




3.8.3 Save & reset



3.8.4 Reset Without Saving




3.8.5 Save Setup Values




SR200-X4-A20 User's Manual

Revision Date: Dec.09.2024


3.8.6 Load Previous Values



3.8.7 Load Optimized Defaults



3.8.8 Save Values as User Defaults



3.8.9 Restore User Defaults

